

IsoCover



- ✓ Easy to install without glue
- ✓ UV resistant and water tight
- ✓ Prevent CUI (Corrosion Under Insulation)

Roll size

70mm	x 10m
140mm	x 10m
280mm	x 10m
560mm	x 10m

Colour

Black
Grey



Simple rules installing IsoCover

- Tools: Scissors, knife, tape measure,
Overlap: Minimum 20 mm overlap,
Outside: Water resistance seams if outside installation
No glue: Vulcanize after 5 - 15 minutes
Installing: Air temperature + 8 to 40 degrees
Flexible: Up to 50% flexible

